

veito

AERO S



THESE INSTRUCTIONS SHOULD BE READ CAREFULLY

SAVE THESE INSTRUCTIONS

User manual

IMPORTANT SAFETY INSTRUCTIONS

Read all instructions before installing or using this heater.

Installation and repair must be carried out by a qualified and licensed person only.

Improper installation, adjustment, alteration, service or maintenance can cause personal injury, property damage or death.

The installer is to ensure that the requirements of the local authority, local electrical installation code, municipal building codes, and any other relevant statutory regulations are carried out.

The manufacturer is not responsible for any damage that could happen from improper use. The manufacturer emphasizes that this appliance should be used in a responsible manner and that all procedures, warnings, and safety instructions contained in this booklet be followed strictly.

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

Use this heater only as described in this manual. Any other use, not recommended by the manufacturer, may cause fire, electric shock, or injury to persons.

Do not install the heater directly near a bathtub, shower or swimming pool. Any switches or controls must not be within reach of a person in the bathtub, shower or swimming pool.

This heater is hot when in use. To avoid burns, do not let bare skin touch hot surfaces. Keep combustible materials, such as furniture, pillows, bedding, papers, clothes and curtains at least 1500mm from the front of the heater and keep them away from the sides and rear.

This heater is not intended for use by persons (including children) with reduced physical, sensory or mental abilities or lack of experience or knowledge, unless they are supervised by a person, which is responsible for their safety or they received instructions from them as the device is used.

Extreme caution is necessary when any heater is used by or near children or invalids and whenever the heater is left operating and unattended.

Children should be supervised to ensure that they do not play with the appliance.

Cleaning and user maintenance shall not be made by children without supervision.

Keep packaging materials out of reach of children.

Children and vulnerable people should be alerted to the hazards of high surface temperatures and should stay away to avoid burns, clothing ignition, or other serious personal injury.

Do not attempt to alter the unit in any manner.

Do not paint any surface of the heater.

Do not touch the heater with wet hands at any time.

Do not insert or allow fingers or foreign objects to enter any ventilation or exhaust opening as it may cause an electric shock or fire or damage the heater.

Do not touch any part of the heater during operation.

Always disconnect the heater from the electricity supply and allow adequate time (minimum of 30 mins.) for it to cool before adjusting the position or attempting to work on it.

Do not use or store flammable materials near this appliance.

Do not spray aerosols or flammable materials in the vicinity of this appliance while it is in operation.

Never operate the heater in an explosive environment such as areas where petrol or other flammable liquids or vapors are stored.

Do not cover the heater.

Clothing or other flammable materials should not be hung from the heater or placed on or near the heater.

After unpacking, make sure the appliance shows no signs of visible damage or tampering. If the appliance appears damaged, contact the place of purchase for assistance.

Check for damage to the appliance regularly. Do not use the heater if the heating element is cracked or broken. If damage to the appliance is suspected, discontinue use immediately and contact the supplier or qualified person to repair.

This heater must only be used on a 120V AC single phase electricity supply.

This heater must be grounded. Connect to properly grounded outlets only.

Ensure both plug and socket is clean and free from dust when using.

To disconnect the heater from the power supply, grip the plug and pull from the power socket. Never pull by the cord.

Do not touch the plug with wet or moist hands.

Do not use an extension cord with this heater.

Do not allow the supply cord to sit or hang in front of the heater while in use and keep it away from the body of the heater which will get hot during operation.

Keep the cable away from sharp edges during handling and installation.

Regularly inspect the power cord and plug for wear or damage and do not operate the heater with a damaged cord, plug or loose socket or after the heater malfunctions, has been dropped or damaged in any manner.

If the supply cord is damaged, it must be replaced by the manufacturer, it's service agent or similarly qualified persons in order to avoid a hazard.

Do not locate the heater immediately above or below a fixed socket outlet or connection box. This is because the heat radiated from the appliance may damage the electricity outlet or plug.

Always unplug the heater when not in use.

The supply cable must be at the lower end of the heater if the heater is installed at an angle or vertically.

For installation use only the supplied accessories or original accessories approved by the manufacturer.

Do not place articles on or against this appliance.

A minimum safety distance of 1500mm should always be left in front of the appliance.

This heater must be mounted at a minimum of 2400mm above the floor.

INTRODUCTION

The AERO S carbon infrared heater is engineered as a robust indoor-outdoor heater. Every component in the AERO S heater is optimized for performance. That includes the veito carbon infrared tube producing mid-wave infrared heat. The AERO S heater has weatherproof design, which means you can use it for patios, terraces, smoking areas, conservatories, restaurants, hotels, garages, workshops, factories, warehouses and many more.

Model: AERO S	Dimensions (W x H x D): 820 x 180 x 55mm
Voltage: 120V AC, 60Hz	Weight: 3 kg
Power: 1500W	IP Rating: IP44

OPERATION

Press one of the **1 2 3 4** buttons on the remote control to turn the heater on.

Press **ON** button to turn on the heater in previous settings.

Press **OFF** button to turn the heater off.

REPLACING THE BATTERY

Press the battery compartment release button and then slide out the battery tray.

Remove the old battery and put the new battery in, making sure that the battery's positive side is facing up. Use only a CR2025 battery in this remote control.

Slide the battery tray back into the remote control until it clicks.

Note: Do not allow water or liquid to get into the remote control.

CLEANING AND MAINTENANCE

Installation and repair must be carried out by a qualified and licensed person only.

Always disconnect the heater from the electricity supply and allow adequate time (minimum of 30 mins.) for it to cool before adjusting the position or attempting to work on it.

If the heater has collected dust or dirt inside the unit or around the heating element, have the unit cleaned by a qualified service agent. Do not operate the heater in this condition.

The only maintenance required is cleaning of the external surfaces of the heater.

Do not use powerful abrasive or solvent cleaning fluids when cleaning the heater. Use a damp cloth to wipe the outside of the heater.

If removed from its mounting position when not in use, store the heater carefully in a safe, dry, childproof location.

Do not touch the heating element with bare fingers, as residue from your hand could affect the life of the lamp. If it is accidentally touched, remove the finger marks with a soft cloth moistened with methylated spirit or alcohol.

Do not attempt to repair or adjust any electrical or mechanical functions on this heater.

The heater contains no user serviceable parts. Check for damage to the appliance regularly. If damage to the appliance is suspected, discontinue use immediately and contact the supplier or qualified person to repair.

INSTALLATION

Installation must be carried out by a licensed and authorized person only.

Only connect the appliance to a power supply that conforms to the specification stated on rating plate.

This heater must be installed according to the minimum installation clearances shown in the diagrams.

The heater should always have a minimum clearance of 500mm from a ceiling and adjacent walls.

Mark and drill the mounting holes on the wall.

Attach the mounting bracket to the wall.


Bring the heater up to mounting bracket. Insert M6 bolts in the slots on the bracket. Lock into position with M6 nuts.



Rotate the heater to require angle and lock into position with the bolt and nut on the wall bracket.

Do not position the heater at an angle of more than 90° and less than 45°.

Plug in to turn the heater on.

WIRING DIAGRAM







For electrical products sold within the European Community.
At the end of the electrical products useful life it should not be disposed of with household waste. Please recycle where facilities exist. Check with your Local Authority or retailer for recycling advice in your country.

