Redfern
Home + Health

OWNER'S OPERATING & CARE MANUAL

Eurosteam® Lint Remover

Heavy-Duty Electric Fabric Defuzzer & Sweater Shaver

Triple Rotary Blades **Precision Honeycomb Foil** **Auto Safety Shut-Off**

Effortlessly removes lint, fuzz, pills, and pet hair to restore knitwear, outerwear, blankets, and furniture. Engineered with fabric-safe protection to revitalize garments without snagging or cutting threads.

Precision Shaving Head

Expanded honeycomb mesh captures pills of all sizes while shielding delicate fabric weaves.

High-Torque Motor

High-speed rotary cutting system shears stubborn pilling from wool, cashmere, cotton, and upholstery.

Easy-Empty Lint Chamber

Large transparent lint collector detaches easily for rapid emptying and mess-free cleanup.

Redfern Enterprises Inc. | www.redfernhh.com | Toll-Free: 1-877-709-3444

Please read this manual thoroughly before operating your device. Retain for future reference.

IMPORTANT SAFETY INSTRUCTIONS 01

When using electrical fabric care appliances, basic precautions must always be followed to reduce the risk of injury, electric shock, or damage to garments.

DANGER — BLADE & MECHANICAL SAFETY:

- **KEEP HANDS AND FINGERS AWAY FROM THE ROTATING BLADE ASSEMBLY.**
  Never remove the outer metal mesh foil or touch the internal blades while the unit is switched ON.
- Do not use the lint remover directly on clothing currently being worn on the human body or pets. Always place the garment flat on an ironing board or solid table.
- Never press with excessive downward force against fabrics; let the high-speed rotating blades glide gently across the surface.
- This unit is equipped with an
  AUTOMATIC SAFETY INTERLOCK SWITCH
  : the motor will automatically disengage if the protective metal foil ring is loosened or removed.

CAUTION — FABRIC & OPERATIONAL PRECAUTIONS:

- Do not use on thin, embroidered, sequined, lace, or snagged garments. Exercise extreme caution around buttons, zippers, loose stitching, and seams.
- Always empty the transparent lint reservoir before it reaches the MAX fill line to prevent motor jamming or reduced suction efficiency.
- Do not immerse the motor body in water or rinse under running water. Clean solely with the included lint cleaning brush.
- Keep out of reach of unsupervised children. Disconnect power / turn OFF when cleaning or storing.

COMPONENT BREAKDOWN & PACKAGE CONTENTS 02

Package Inclusions

- **1x Eurosteam® Lint Remover:** Motorized defuzzer unit.
- **1x Honeycomb Mesh Foil:** Protective stainless steel screen.
- **1x Rotary 3-Leaf Blade:** Precision stainless steel cutting blades.
- **1x Height Adjustment Spacer:** For delicate / high-pile knits.
- **1x Detachable Lint Chamber:** Transparent waste bin.
- **1x Cleaning Brush:** For blade & mesh maintenance.

Key System Advantages

Fabric Rejuvenation Technology

The Eurosteam® Lint Remover draws fabric pills, fuzz balls, and shed fibers through multi-sized honeycomb mesh perforations. The high-speed rotary blade shears pills cleanly at the surface level without pulling yarn or fraying underlying knit fibers.

Multi-Surface Versatility: Restores sweaters, wool coats, cardigans, fleece, blankets, pillows, car upholstery, sofa cushions, and pet-hair covered fabrics.

OPERATING INSTRUCTIONS & BEST PRACTICES 03

Follow these step-by-step instructions to safely defuzz and restore your favorite garments:

STEP 1 **Garment Preparation:** Lay the garment completely flat on a firm, level surface (e.g., an ironing board or solid table). Smooth out all wrinkles, folds, or bunches with your hands.

STEP 2 **Inspect Garment:** Check the surface for loose threads, open seams, buttons, hooks, or protruding zippers. Avoid direct contact with these areas during shaving.

STEP 3 **Safety Spacer Adjustment:** For long-hair knits, mohair, or delicate woolens, attach the height adjustment spacer to maintain safe blade clearance. For tight-weave cottons and synthetics, use standard foil contact.

STEP 4 **Powering ON:** Slide the power switch to the **ON (I)** position. The motor will hum smoothly as the rotary blades spin up.

STEP 5 **Shaving Technique:** Hold the unit by its ergonomic grip. Move the shaver in small, light circular motions across the fabric surface. Do not push down firmly into the fabric.

STEP 6 **Powering OFF:** Slide switch to **OFF (O)** once complete. Empty the lint container before storing.

FABRIC-SPECIFIC SHAVING TECHNIQUES 04

Sweaters, Knits & Woolens

- Keep the knit fabric taut with your free hand while shaving.
- Follow the grain/weave of the knit in gentle, parallel strokes, followed by light circular passes.
- Exercise extra care around armpit seams, collar ribs, and sleeve cuffs where friction pilling is densest.

Furniture, Blankets & Outerwear

- For sofa cushions, blankets, and wool jackets, use broad overlapping circular motions across wide sections.
- Empty the lint chamber frequently, as large items generate higher fiber volume.
- Great for removing embedded pet hair from fleece throws and car upholstery.

CLEANING, MAINTENANCE & TROUBLESHOOTING 05

Emptying the Lint Chamber

- Slide the transparent lint collection bin downward away from the main handle.
- Empty collected lint and fuzz directly into a waste bin.
- Slide the chamber firmly back into place until it clicks securely.

Cleaning Blade & Honeycomb Mesh

- Ensure unit is powered **OFF** and disconnected.
- Unscrew the metal honeycomb mesh counter-clockwise.
- Carefully lift out the 3-leaf blade by its plastic center shaft. *Blades are sharp.*
- Use the included brush to sweep lint from blades, mesh holes, and motor spindle.

Problem Encountered	Probable Cause	Recommended Corrective Action
Motor does not run	Power disconnected, or safety interlock activated.	Check power / batteries. Ensure the metal mesh foil is screwed on fully to engage the safety interlock switch.
Motor runs slowly / weak cutting	Lint chamber full, or hair wrapped around spindle.	Empty the lint container. Remove outer mesh and clean compacted fiber buildup from blade hub using the brush.
Fabric snags or tears	Excessive pressure applied, or mesh guard bent.	Do not press into fabric; glide lightly. Inspect mesh for dents; replace damaged mesh immediately.
Excessive rattling or vibration	Blade assembly loose or improperly seated.	Unscrew mesh, ensure 3-leaf blade is seated squarely onto the drive spindle, and re-tighten mesh guard.

SPECIFICATIONS & WARRANTY 06

Product Name	Eurosteam® Fabric Lint & Pill Remover
Brand / Manufacturer	Eurosteam® / Distributed by Redfern Enterprises Inc.
Cutting System	Precision 3-Leaf Stainless Steel Rotary Blade System with Safety Interlock
Suitable Fabrics	Wool, Cashmere, Cotton, Synthetics, Fleece, Linens, Upholstery & Pet Blankets
Warranty Period	1-Year Limited Manufacturer Warranty (Excludes Consumable Blade Wear)

Redfern Enterprises Customer Care

Canada Head Office: 101-127 Commercial Drive, Calgary, AB T3Z 2A7 | **Toll-Free:** 1-877-709-3444 | **Email:** info@redfernent.com

USA Office & Warehouse: 4168 N Pecos Rd, Ste 102, Las Vegas, NV 89115 | **Toll-Free:** 1-877-462-5757 | **Email:** infous@redfernent.com

Visit us online at **www.redfernent.com** or **www.eurosteam.ca** for replacement blades, accessories, and product support.