

ShowerMe®

MULTIFUNCTIONAL ELECTRIC SHOWER BRUSH

3 Different speed adjusment and
brush 360° rotation to deeply cleanse your skin

Brush head: 5 large brush heads
Product weight: about 535g
Handle length: 40cm
Product size: 40*10*7.5cm
Gear position: 3 Speed Adjustment
Waterproof grade: IP67 grade
Loading and unloading function: Snap-on removal handle
Rated voltage: 3.7V
Rated power: 10W

The bath brush and massage brush head should be cleaned
after use to enhance cleaning performance and
Service life:

1. Wash with mild detergent and soft sponge to keep the whole bath brush clean, dust-free and dirt-free.
2. When cleaning the whole electric bath brush, please pay attention to the state that the battery charging port is completely sealed before cleaning, so as to prevent water from infiltrating and damaging the electrical components and affecting the service life.
3. Please store the product indoors.

How to dispose of rechargeable batteries

1. The built-in rechargeable lithium battery of this product contains substances that may pollute the environment. When discarding this product, please do not put it with general household waste, and the battery should be taken out.
 2. Be sure to turn off the power or power off before disassembling the product and taking out the lithium battery.
 3. Steps to take out the lithium battery: Pry open the clasp of the upper cover of the product, open the upper cover of the product, and then take out the lithium battery.
 4. The removed lithium battery should be disposed of safely and put into the battery recycling center designated by the government, which is conducive to environmental protection.
- Special Note: Only take out the battery when disposing of this product. Before taking it out, make sure that the battery is exhausted. Non-professionals should not disassemble it.

How to dispose of rechargeable batteries

Question	Solution
Device Won't Charge	Check whether the power adapter is connected to a working socket; whether the power adapter and data cable are damaged;
Device Won't Turn On	The device cannot be turned on during the charging process; the device is out of power, please charge it;
Decreased Cleaning Power of Equipment	The bristles of the massage brush head are worn, please replace the accessories;

1 Year Limited Warranty

This product is warrantied for 1 year from the original date of purchase, against defects in materials and/or workmanship when utilized for normal household use. During this period if the unit is proved defective it will be repaired or replaced at the discretion of the service technician.

The unit shall be returned, by original purchaser, freight prepaid with proof of original purchase date and \$29.99 return shipping/handling charges included. Redfern Enterprises does not accept C.O.D.'s and will not reimburse for any fees associated with the return or shipping of the item.

This warranty does not apply to any defect arising from a buyers misuse, negligence, failure to follow instructions, use on current or voltage other than that stamped on the unit or repairs not authorized by a Redfern Ent. technician will null and void the warranty. If you believe that your product is defective, contact Redfern Enterprises Customer Services Department:

CANADA
101-127 Commercial Drive,
Calgary, AB T3Z 2A7
TF: 1-877-387-7770 (Toll Free)
info@redferment.com www.redferment.com

UNITED STATES
4168 N North Pecos Road, Ste 102
Las Vegas, Nevada, 89115
1-877-462-5757 ext. 1 (Toll Free)
infous@redferment.com
www.redfermentus.com


Obtain a repair authorization number (RA Number) and bring in or send prepaid to the Service Center with proof of original purchase date, and prepaid return shipping of \$29.99. See contact info above for RA Number.



ShowerMe®


MULTIFUNCTIONAL ELECTRIC SHOWER BRUSH

3 Different speed adjusment and
brush 360° rotation to deeply cleanse your skin




Description

The multifunctional electric shower brush consists of three parts. Handle, host and massage brush head. The unique design concept makes it easier to replace the bath massage head. Five different massage heads make it suitable for different body parts. The rotating massage head has a gentle and moderate friction when in contact with the body. It cleans the skin and has the massage effect that allows the user to relax and experience a soothing bath or shower. The extended and detachable handle design makes using this brush easier for all types of body sizes. With a high quality and soft leather sealed and waterproof design, you can feel the ease of use in full comfort.



CE RoHS

5 Brushes and Suggestive Uses




Body Cleaning Brush

Deeply clean pores to help improve skin and remove shine.




Comfort Shower Brush

Great in baths to gently clean skin and sensitive areas.




Body Scrub Brush

Deep clean body scrub brush for a fulfilling pure clean.



EXFOLIATING FOOT BRUSH

Helps to improve and smooth heels and rubs off dead skin.



DEEP CLEANING BRUSH

Helps to remove dead cells and make skin feel healthy and rejuvenated.

Precautions

1. Before using this product, please read the safety instructions carefully; please keep this manual for future reference.
2. This product is only used as a household appliance and is not suitable for medical appliances or industrial purposes.
3. Before use, please check the equipment and its accessories for visible damage. Check whether the massage brush head is firmly installed to avoid the rotating brush head falling off and hurting people.
4. Children under the age of 8 and the disabled should use it under the guidance of adults.
5. Do not operate this product near inflammable and explosive objects or liquids.
6. When the product is running, keep your hair and loose clothes away from the machine.
7. When the product is turned on and running, do not insert any accessories.
8. Do not use this product in the following situations: damaged skin, open wounds, skin diseases or skin allergies, just sunbathing, taking steroid-containing drugs.
9. Please keep away from the water source when charging, and do not charge near the bath, tub or other liquid containers containing water.
10. Do not rotate brush head forcibly by hand.

Instructions for use

1. Please charge for 2 hours for the first use. Please use a DC5V, 1A or 2A power adapter for the charging power supply. Open the sealing cover of the charging port. The red indicator light flashes when charging, and the green light is always on when fully charged. Be sure to cover the sealing cover after charging is complete.
2. Align the required massage brush head with the hexagonal card slot, press up to fix it on the electric shower brush, and confirm that the installation is firm before use.
3. When you need to replace the massage brush head, pull it out, you can choose five kinds of massage brush heads.
4. The handle can also be installed on the electric bath brush, by using the long handle to wash hard to reach areas such as the back and lower body.
5. Wet the skin, squeeze the shower gel or lotion on the brush head, long press the power or gear button to turn on the machine, the speed of this product is set to 3 speeds, the default slowest speed is 1 when starting up, and short press the power or speed. The position key can cyclically adjust the speed from 1 to 3 speeds, and the indicator lights correspond to blue, green, and red respectively it is recommended to start from speed 1 for the first use.
6. In order to ensure the comfort during use, please do not push brush head hard up against your skin. When the brush head is squeezed too hard, the product will stop working and the indicator light will flash 3 times. After releasing it, you can continue to use.
7. Hold and press the power or speed button to turn on/off the power to rinse with water and let it air dry.

